


## USB-CW (LD-C103) Setting

For example, the CwType.

- 1、Please read 'Setup\_Readme' and Setup the USB-Serial CH340 drive .
- 2、Install CwType



- 3、Setup CwType **【Key = RTS】**



**@2018 USB-CW**

**【Key = RTS】**